



THIS DOCUMENT WAS  
 ORIGINALLY SEALED AND  
 ISSUED BY RYAN L. SCHMITZ  
 E-13818, ON 6-14-2023. THIS  
 MEDIA SHOULD NOT BE  
 CONSIDERED A CERTIFIED  
 DOCUMENT AND SHOULD BE  
 USED FOR REFERENCE ONLY.

NOTES:

1. A SERVICE SADDLE SHALL BE REQUIRED FOR ALL 1- $\frac{1}{2}$ " AND LARGER TAPS ON ALL MAINS REGARDLESS OF PIPE THICKNESS CLASS.
2. USE ADDITIONAL ENLARGED BASE WITH STANDARD 94-E BOX ON ALL 1- $\frac{1}{2}$ " AND 2" CURB STOPS.
3. PIPE STRAIGHTENER INSERTS SHALL BE INSTALLED AT ALL COMPRESSION FITTINGS WHEN CTS POLY PIPE IS USED
4. TRACER WIRE SHALL BE REQUIRED WHEN USING CTS POLY PIPING. REFER TO STANDARD PLAN I63 FOR REQUIREMENTS.